

Template 1

PORTA on/offCHORUS on/off

place it on the upper left panel

123

LFO RATE
PORTA TIME
VCA LEVEL

LFO DELAY
DETUNE
VCA ENV MODE

CHORUS RATE
MOD SENS
VCA AFTERTCH

12

PULSE WAVE
KEY ASSIGN

SAW WAVE
CHORD MEM

SUB OSC WAVE
TONE NUMBER

SUB OSC LVL
PATCH NUMBER

NOISE LVL
VOLUME

DCO/MIXER

OCTAVE RANGELFO DEPTHENVELOPE DEPTHENVELOPE MODEAFTERTOUCH DEPTHPULSE WIDTHPWM RATE (0 = manual)BENDER RANGE

DCOROLAND PG300 EMULATOR

HIGH PASS FILTER (0=bass boost)FILTER FREQUENCYFILTER RESONANCELFO DEPTHENVELOPE DEPTHENVELOPE MODEKEY FOLLOWAFTERTOUCH DEPTH

VCFPROGRAMMING & GRAPHICS by SIZZLEMEISTER

ATTACK TIMEATTACK LVLBREAK TIMEBREAK LVLDECAY TIMESUSTAIN LVLRELEASE TIMEKEY FOLLOW

ENVELOPE

Please note that you print with Zoom 100%