

Encoder

- Encoder 1~8: V-Pot 1-8 (All Groups)
- Group 1 Push Encoder : Mute Track 1~ 8
- Group 2 Push Encoder : Solo Track 1~ 8
- Group 3 Push Encoder : Track Arm 1~ 8
- Group 4 Push Encoder : V-Select 1~ 8
- Encoder 33~40 : Fader 1~8
- Encoder 41 : Jog Wheel
- Encoder 42 : Master Fader
- Encoder 43~56 : Standard MIDI CC(for Live5 MIDI Mapping mode)

Button

- Button 33~40 : Track Select 1~8

Button 33~48

MCE3 Live

Pan	Send	Plug-in	Page←	Page→	Option	Zoom	Scrub
-----	------	---------	-------	-------	--------	------	-------

add-on

Marker	Marker←	Marker→	Undo	Redo	BTA	tgl view	Control
--------	---------	---------	------	------	-----	----------	---------

Button 53~56

Bank ←	Bank →
Flip	View

Button 49~52

MCE3 Live

Play	Stop
Rec	Loop

add-on

Punch In	Punch Out
Rew	Fwd

Bank button : 9 or more track

Flip button : V-Pot  Fader

Zoom : Launch Clip

Option+Zoom : Stop Clip

Scrub : Launch Scene

Option+ Scrub : Stop Scene

Jog Wheel : Move the play position (Arrangement View)

Select Scene (Session View)

Control+ Jog Wheel : Tempo Change

Send

1. select a track
2. press the “Send” button

Plug-in Control

1. select a track
2. press the Group 4 button
3. press the “Plug-in” button
4. push the “V-select” (Group4 encoder push)

Slot	EQ >	Compressor >	Delay>
V-select	1	2	3

* 9 or more parameter : Use “Page” buttons