


11 ADJUSTMENTS

MIDI Pickup Adjustment

Adjust the MIDI pickup so that the clearance between the 1st and 6th strings and the pickup is as shown below.



When the MIDI pickup height is set as above, the clearances between the 2nd ~ 5th strings and the pickup are automatically set within 0.5 mm to 0.8 mm.

If the clearances are not within the said value, perform the bridge height adjustment as shown on page .

