

Preset Name:

Roland TB-3 by nig@airainfo.org

E1	Cutoff	Resonance	Accent	Effect	ENV MOD X	ENV MOD Y	Pad Z	Pad Y	E 1-8
E2	Scatter Type	Scatter Depth	Tuning	Patch Slide	Patch Accent				E 9-16
E3	SAW Level	SQR Level	White Noise Level	Pink Noise Level	Decay	Volume			E 17-24
E4	SAW ON/OFF	SQR ON/OFF	White Noise ON/OFF	Pink Noise ON/OFF					b 17-24
	Drive	Bottom	Tone	Effect Level	Dry Level				E 25-32
	Distortion ON/OFF	Distortion Type							b 25-32
									b 33-40
	EFX1 ON/OFF	EFX1 Type			EFX2 ON/OFF	EFX2 Type			b 41-48

E 33-40	EFX1 Par 2	EFX1 Par 3	EFX1 Par 4	EFX1 Par 5	EFX2 Par 2	EFX2 Par 3	EFX2 Par 4	EFX2 Par 5
E 41-48	EFX1 Par 6	EFX1 Par 7	EFX1 Par 8	EFX1 Par 9	EFX2 Par 6	EFX2 Par 7	EFX2 Par 8	EFX2 Par 9
E 49-56	EFX1 Par 10	EFX1 Par 11	EFX1 Par 12		EFX2 Par 10			

FOOTSWITCH

FS 1

FS 2

: PUSH

: TURN/MOVE

EDIT MODE:

1. PUSH & HOLD EDIT

2. PUSH/TURN/MOVE CONTROL ELEMENT

3. RELEASE EDIT

4. PUSH ENCODER

1: MIDI Data Type
2: MIDI Send Ch.
3: Parameter
4: Value 1
5: Value 2
6: Controller Mode
7: Controller Option
8: Display Value

5. PUSH EXIT

GLOBAL MODE:

1. PUSH & HOLD EDIT

2. PUSH STORE

Global Mode selected

3. PUSH ENCODER

1: Operating Mode
2: Global RX Ch.
3: Footswitch
4: Start Preset
5: Device ID
6: SysEx Dump
7: Adjustable dead time (ms)
8: MIDI Data Interval (ms)

4. PUSH EXIT

ENCODER GROUP COPY:

1. SELECT SOURCE ENCODER GROUP

2. PUSH STORE

3. SELECT DESTINATION ENCODER GROUP

4. PUSH STORE

STORING RECEIVED SINGLE PRESET DUMP:

1. Send Single Preset Dump from external device to B-CONTROL's MIDI IN or USB

2. PUSH STORE

3. SELECT desired destination preset

4. PUSH STORE

PRESET STORE/COPY/OVERWRITE:

1. PUSH STORE

2. SELECT PRESET destination

3. PUSH STORE

LEARN MIDI DATA:

1. PUSH & HOLD LEARN

2. PUSH/TURN/MOVE CONTROL ELEMENT

3. RELEASE LEARN

4. Send MIDI data to B-CONTROL

PANIC RESET:

1. PUSH & HOLD EDIT

2. PUSH EXIT

Panic Reset done

DATA REQUEST:

1. PUSH & HOLD EDIT

2. PUSH LEARN

Data Request done

PRESET RECALL:

1. SELECT PRESET

or

1. HOLD & TURN PRESET

2. RELEASE PRESET

SNAPSHOT SEND:

1. PUSH & HOLD EDIT

2. PUSH PRESET

Control Data sent

SINGLE PRESET DUMP:

1. PUSH & HOLD EDIT

2. PUSH PRESET

Single Preset Dump sent