

All measurement was made with a type K thermocouple on iron tip (in center of a alloy ball).

Temperatures range	Potentiometer settings			
TEMP.HEATER ON	134	164	256	292
Temp.diference between ON & OFF	8	12	7	10
TEMP.HEATER OFF	142	176	263	302
Temp.diference between OFF & MAX	20	18	15	14
TEMP.MAX	162	194	278	316
Total diference between ON & TEMP.MAX	28	30	22	24

Time for cool down from 300°C to 150°C is 3'30".
 Heating time from 150°C to 300°C is 25".

